

REPLACEMENT PAGE

Applicant - Strait

Serial No.: 10/616,030

Docket No.: 0545.033

Title: Bearing Assembly Spacer Adjustment System and Method for Adjusting a Spacer

1/6




FIG. 1

PRIOR ART




FIG. 2

3/6




FIG. 3




FIG. 4

REPLACEMENT PAGE

Applicant – Strait

Serial No.: 10/616,030

Docket No.: 0545.033

Title: Bearing Assembly Spacer Adjustment System and Method for Adjusting a Spacer

5/6




FIG. 5

REPLACEMENT PAGE

Applicant – Strait

Serial No.: 10/616,030

Docket No.: 0545.033

Title: Bearing Assembly Spacer Adjustment System and Method for Adjusting a Spacer

6/6




FIG. 6